


Connection accessories

Terminal adaptors - Pole interconnection links for 4P contactors

For LC1DT20...
DT25



Terminal adaptor
for 10 mm² cables
LA9D1260

Lot of 1

To be inserted into 4P contactor screw clamp or screw type terminals. 90° connection angle between cable and contactor terminal.



1 terminal adaptor
for 10 mm² cables
LA9D2560

Lot of 1

To be inserted into 4P contactor screw clamp or screw type terminals. Straight connection between cable and connector terminal.



Terminal for 2P
parallel connection
LA9D1261

Lot of 10

For connecting one single cable into 2 terminals in parallel.



1 terminal for
parallel connection
LA9D1263

Lot of 2

For connecting one single cable with a ring lug into 4 terminals in parallel.



1 terminal for 2P
parallel connection
LA9D2561

Lot of 10

For connecting one single cable into 2 terminals in parallel.



1 terminal for 4P
parallel connection
LA9D2563

Lot of 1

For connecting one single cable into 4 terminals in parallel.

For LC1DT40...
DT65



2P parallel links
LA9D40961

Lot of 2

For connecting one single cable with a ring lug into 2 terminals in parallel.



4P parallel links
LA9D40963

Lot of 2

For connecting one single cable with a ring lug into 4 terminals in parallel.

For LC1D60A6...
D80A6



4P terminal
protective cover
LAD96580

Lot of 1

To be inserted on screw type terminal (for lugs) of contactors. Prevents from direct contact with live lugs.

For LC1DT80...
DT95



Control circuit take-off
from main pole
LA9D8067

Lot of 10

To be inserted into a power screw clamp terminal, it provides a smaller terminal for a control circuit connected to the same voltage.